


# NEWMAR<sup>®</sup>

*Powering the Network<sup>SM</sup>*

## Installation/Operation Manual

### Model: Scout Power System, 12V



#### Features


- 1 RU low profile, 19 inch rack mounting
- Programmable digital controller and system monitor
- Front panel LCD display provides system status
- USB, RS-232 or Ethernet interface for PC connection locally or remote monitoring and control via modem
- Alarm/event log with time and date
- Windows based PC communication software
- Easy wire connections on rear panel
- 4 user programmable relay outputs for traditional remote monitoring or warning
- 2 year warranty

## Table of Contents


Section	Page
Quick Reference Guide.....	0
0. Safety Guidelines.....	1
1. Materials Provided.....	1
2. Quick Start Installation/Wiring/Set-Up.....	1
3. Functions.....	2
3.1 Scout Monitoring Functions.....	2
3.2 LED Indicators and LCD User Interface.....	2
3.3 Communication and Operation Interface.....	2
3.4 Real Time Clock, Data Log and Event Log.....	2
3.5 Programmable Relays and Digital Input Signals.....	2
3.6 Alarms.....	3
3.7 PMBus Communication Interface.....	3
4 Scout LCD User Interface.....	3
4.1 Description of SCOUT Front Panel.....	4
4.2 Status Menu.....	4
4.3 Settings Menu.....	4
4.4 Maintenance Menu.....	6
4.5 Network Menu.....	6
5. Scout-S Web Page Monitoring Functions.....	7
5.1 IP Settings of PC.....	7
5.2 Description of Scout-S Built-in Web Page.....	9
5.3 Event Log Page.....	12
5.4 Data Log Page.....	13
5.5 TCP/IP Configuration Page.....	13
6. Scout-S Monitoring Software.....	14
6.1 Installation.....	14
6.2 Using RS232 for Communication with Scout-S.....	15
6.3 Description of Scout-S Monitoring Software.....	15
7. GSM Short Message Functions.....	22
7.1 Installation and Settings.....	22
7.2 Test of Sending a Short Message.....	23
7.3 AT-Command List for Scout-S.....	23
8 EMI Suppression Arrangement.....	23
9. Troubleshooting.....	23
10. Warranty and Contact Information.....	23
Appendix A - J.....	24

# Quick Reference Guide

## Front Panel View



## Rear Panel View



### Rear Panel References

- 1) RJ45 Port (JK-1) used when paralleling multiple shelves
- 2) RS-232 Port (DB9) - SMBus output for system monitor
- 3) Digital input for integrating auxiliary alarms
- 4) Form C programmable alarm relay contacts (RY1 RY2 RY3 RY4)
- 5) 12 VDC power feed to controller (provided by rectifier output)
- 6) DB 25 connector - mating connector RKP-1U must be installed for system operation
- 7) Power module address setting for serial SMBus for remote monitoring,

**Factory preset:** Module A on-on-on-on-on  
Module B off-on-on-on-on

## 0. Safety Guidelines

- Risk of electrical shock and energy hazard. All failure should be examined by a qualified technician. Please do not remove the case cover from the unit
- Please do not change any component on the unit by yourself or make any kind of modification on it
- Please do not install the unit in places with high moisture, high ambient temperature or under direct sunlight
- Please do not feed in voltage that is over or less than 10% of the rated value. Refer to the safety label on the unit
- The safety protection level of this unit in class 1. As a result, the "Frame Ground"  $\perp$  on the rear of the racks unit must be well connected to earth ground. The total leakage current of the whole system, including two Scout Rectifiers (Scout-R), is less than 2.3mA

## 1. Materials Provided

### Materials Provided with Shelf\*

Quantity	Description
1	Scout-S System Shelf
2	19" Mounting Ears
4	10/32 x 3/8" Flat Head Mounting Ear Screws
2	1/0 AWG Terminal Lugs
1	Rectifier Blank Plate
8	10/32 x 3/4" Load Screws
1	RKP-1U Connector (must be installed for system operation)
1	PC Cross-Over Cable
1	Installation/Operation Manual Short Form

\* Note, AC power cord provided in box with rectifier

## 2. Quick Start Installation/Wiring/Start-up

- 1) Attach rack mounting ears to shelf using the provided #10-32 x 3/4" flat head screws.
- 2) Install in a 19" rack with a minimum of 4" clearance from front and back of shelf to allow for adequate fan ventilation (for installation in a 23" rack, contact Newmar and request SRS-1U 23" adapter set).
- 3) Insert power modules in shelf, and blank plate provided if only one power module is installed. Ensure that the securing latch located on left edge of rectifier face clicks in to place.
- 4) Plug in power cords provided with rectifiers into IEC sockets at rear of shelf. Rectifiers accept universal input 90-264 VAC 46-63 Hz. Maximum current draw per rectifiers is 13 amps @ 115 VAC / 7 amps @ 230 VAC. Remove and replace the NEMA 5-15 end plug if necessary to match the outlet configuration at your site. If replacing, the power cord utilizes 14 AWG minimum wire size for 115 VAC input or 16 AWG for 220 VAC input.
- 5) Attach DC output wiring directly to 12 volt load, distribution panel or battery. Lugs for 1/0 wire are provided for bulk output connection, or attach multiple smaller gauge cables if necessary for your wire routing configuration. Reference table 1 wire size guide. When making a connection to a battery install a fuse on the +12 VDC side (Hot) as close to the battery terminal as practical.
- 6) Connect interface cable(s) (USB/RS 232), programmable relays, digital input signals depending on your application.
- 7) Install RKP-1U in location 6.
- 8) Power on system: LCD read out on front panel will display system data, use key pad buttons to scroll through menu and make settings.

# SCOUT-S / SCOUT-R

## Installation/Operation Manual

### 0. Safety Guidelines


- ⊙ Risk of electrical shock and energy hazard. All failure should be examined by a qualified technician. Please do not remove the case from the unit.
- ⊙ Please do not change any component on the unit by yourself or make any kind of modification on it.
- ⊙ Please do not install the unit in places with high moisture, high ambient temperature or under direct sunlight.
- ⊙ Please do not feed in voltage that is over or less than 10% of the rated value. Refer to the safety label on the unit.
- ⊙ The safety protection level of this unit is class I. As a result, the "Frame Ground" ( $\neq$ ) on the rear of the rack unit must be well connected to earth ground. The total leakage current of the whole system, including two Scout-R units, is less than 2.3mA.

### 1. Introduction

The Scout-S is a dedicated monitor unit for SCOUT-R 12V 100 Amp Rectifiers . It provides the management task of Scout-R for use in telecommunication, monitoring systems, servers, etc. It can be stand-alone operated or integrated into a 19-inch rack.

#### 1.2 Features

- ⊙ 1U low profile/19-inch rack mounting.
- ⊙ Control and monitor Scout-R units.
- ⊙ Front panel LCD and buttons for on-site service without PC.
- ⊙ USB, RS-232, or Ethernet interface for PC connection locally or remote monitoring and control via GSM modem.
- ⊙ Alarm/event log with time and date.
- ⊙ Windows-based PC communication software.
- ⊙ Easy wire connections on rear side.
- ⊙ 4 user programmable relay outputs for traditional remote monitoring or warning.
- ⊙ 2 years warranty.



### 2. Quick Start

#### ⊙ AC wiring-

An IEC C19 style power cord with standard 115 VAC/15 A plug is provided with each rectifier. If you require a different plug end this plug can be cut off and the correct plug end for the outlet at your site attached. Rectifiers have universal input of 90-264 vac, 46-63 Hz. Maximum ac current draw is 13 Amps @ 115 vac or 7 Amps @ 230 vac.

#### ⊙ DC wiring-

Connect the Scout-S shelf DC output terminals using the #10-32 hardware provided to either the load, 12 vdc load distribution panel or directly to a 12 vdc battery. We recommend a battery fuse be installed as close to the battery HOT terminal as practical. Size the fuse to protect the wire size chosen. We recommend fuse value of 125-150% of maximum current.

Scout controller power note: The input power for the controller is provided via a 2.1mm ID, 5.5mm OD barrel plug on the rear panel (SK100). The power source is pre-wired from the factory to allow the Scout-S shelf output voltage to provide this power, **RKP-1U connector must be installed on CN500 located at rear of Scout-S or system will not power up (Figure 1)** . When using 12 volt batteries the batteries will keep the controller powered during an ac power interruption. If not using batteries an external 12V / 1Amp DC adapter connected to a UPS should be used for system monitoring to be maintained.

RKP-1U must be installed unless external 12V (DC IN) is supplied to SK100




Figure 1



## Installation Method

- ⊙ Mount the Scout-S in a 19" rack before operating.
- ⊙ Insert 1~2 units of Scout-R with the identical output voltage and current into the Scout-S.
- ⊙ Assign their addresses through the 5-pole Address Switches (refer to App. I). Definition of the module position: A is in the middle and B is on the left.
- ⊙ This unit is equipped with built-in DC fans and requires clearance for cooling. There should be no barriers within 4 inches of the ventilation holes.
- ⊙ Connect the AC inputs of A and B units to AC source.
- ⊙ Recommended input/output wires are in App. C .
- ⊙ Wire up your interface cable (USB/RS232), programmable relays, and digital input signals, depending on your application. Apply a 12~15 VDC to the SK100 port on the rear of the Scout-S (if external 12V supply used).

## 3. Functions

### 3.1 Scout-S monitoring functions

As a power management device, the Scout-S is capable of monitoring 32 units of Scout-R at the same time. It not only can read the operating parameters or data (such as output voltage, output current, internal temperature, working status, series number, and firmware version) from the units, but also can be used to adjust the values of bus voltage and PSU current. In addition, it can remotely turn the Scout-R units on/off by the command of "PMBus OPERATION" (pin6,7 JK1).

### 3.2 LED Indicators and LCD User Interface

There are LED indicators on the front panel of the Scout-S that are used to display system operating status. Refer to App. E for details.

Besides that, there are also a LCD screen and control buttons on the front panel, the LCD user interface. It can be used to monitor, manage, and control your system without using other equipment.

### 3.3 Communication and Operation Interface

The Scout-S uses PMBus as the communication interface to communicate with Scout-R units to monitor, manage, and control these units.

The Scout-S can link to a PC (personal computer) via USB, RS232, or Ethernet, and through the operation interface at the PC side (like monitoring software or Microsoft Internet Explorer), management of the rack power can be consolidated at the PC side as shown in Figure 3. Details will be described in the following chapters.



Figure 3 Diagram of the communication interface of the Scout-S

### 3.4 Real Time Clock, Data Log and Event Log

The Scout-S has a built-in real time clock to display actual date/time for log timestamp. The Data Log is used to store the operating data of the rack power system. It has 1000 records and the interval of log is programmable from 1 to 60 minutes. The Event Log is designed to store abnormal system condition when an alarm occurs and removes. There are up to 600 records of Event Log that can be stored in the Scout-S.

### 3.5 Programmable Relays and Digital Input Signals

To fulfill the requirements of industrial applications for the rack power system, the Scout-S offers 4 digital input signals in CN503 and 4 programmable relays in TB4. In addition, these relays provide both normally-open (N.O.) and normally-closed (N.C.) operations for selection. The operating conditions of the relays are shown in App. H.

### 3.6 Alarm

When an abnormal situation occurs, the red LED indicator on the front panel will flash. The abnormal situation detected can be interpreted on the LCD screen or your computer. Abnormal situations and the descriptions are shown as below.


	Status	Description
Scout-R's abnormal situations	OVP	Over voltage protection
	OLP	Overload protection
	Short circuit	Output short circuit protection
	OTP	Over temperature protection
	High temp.	Internal over temperature alarm
	AC fail	Low AC power shutdown
	Fan lock	Fan malfunction protection

### 3.7 PMBus Communication Interface

The Scout-S is equipped with all the PMBus commands that Scout-R needs. This makes it easy for users to monitor, manage, and control their Scout-R power systems by means of the LCD user interface or the Windows based user interface. Moreover, the unit is compliant with PMBus Rev. 1.1 (the maximum communication speed is 100 KHz) and has the capability of identifying up to 32 addressed units.

#### 3.7.1 PMBus Device Addressing

Each Scout-R unit should have their unique and own device address to communicate over the PMbus. 7-bit address setting pins are used to assign a device address for a Scout-R unit, as the description shows below .



A0~A4, five of the bits, can be set via a 5-pole DIP switch on the rear panel of a rack unit. The "ON" position represents logic "0" while the "OFF" position represents logic "1".

There are 32 different addresses available to be assigned by the DIP switch. The switch settings show in App. I



#### 3.7.2 PMBus Command List

App. J shows the command list of Scout-R. It is compliant with the standard protocol of PMBus Rev. 1.1. For more detailed information, please refer to PMBus official website (<http://pmbus.org/specs.html>).

#### 3.7.3 PMBus Data Range and Tolerance

All of the PMBus data are fully digitalized. The Scout-S uses the data read from Scout-R units to display their operating values and control these units. Please refer to the definition of Scout-R, as shown in App. K, for Display / Control tolerance.

## 4. Scout-S LCD User Interface 4.1




Figure 2 Diagram of Scout-S front panel

## **4.1 Description of Front Panel**

### **4.1.1 Main Page**

The "Main Page" displays the current Bus voltage and total output current.

In the "Main Page", once you press the "ESC" button for over 1.5 sec, you will enter the "Sub Screen", where you can adjust the brightness of LCD backlight and the LCD contrast ratio. There are 8 levels available for both the LCD backlight and the LCD contrast to be selected.

In the "Main Page", once you press the "ENT" button, you will enter the "Menu Page". There are "Status Menu", "Settings Menu", "Maintenance Menu", and "Network Menu" that can be selected through the "UP"/"DOWN" buttons in this screen.

Under the "Status Menu", status information, including Bus voltage, total output current, numbers of PSUs in parallel, PSU

### **4.2 Status Menu**

current, PSU temperature, PSU status, PSU serial number, PSU manufacture date, PSU firmware version, condition of digital input signal, condition of programmable relay, date, and Scout-S information, can be selected through the "UP"/"DOWN" buttons.

#### **4.2.1 PSU Current**

In the "PSU Current" section, each of the PSU's output currents can be displayed by pressing the "ENT" button.

Once you entered this page, you can choose one of the PSU's output currents to be displayed on the screen through the "UP"/"DOWN" buttons. "xx" indicates PSU's number.

When "N/A" is displayed on the screen, it means that the number of unit is offline.

#### **4.2.2 PSU Temperature**

In the "PSU Temperature" section, each of the PSU's temperatures can be displayed by pressing the "ENT" button.

Once you entered this page, you can choose one of the PSU's temperatures to be displayed on the screen through the "UP"/"DOWN" buttons.

When "N/A" is displayed on the screen, it means that the number of unit is offline.

#### **4.2.3 PSU Status**

In the "PSU Status" section, each of the PSU's statuses can be displayed by pressing the "ENT" button.

Once you entered this page, you can choose one of the PSU's statuses to be displayed on the screen through the "UP"/ "DOWN" buttons. If an abnormal situation occurs, the screen will display which PSU unit is and its situation, no matter which unit you have chosen. Abnormal situations that can be displayed include OVP, OLP, OTP, Short Ckt, High temp., AC fail, and fan lock.

#### **4.2.4 PSU Serial Number**

In the "PSU Serial No." section, each of the PSU's serial numbers can be displayed by pressing the "ENT" button.

Once you entered this page, you can choose one of the PSU's serial numbers to be displayed on the screen through the "UP"/"DOWN" buttons.

Once you entered this page, you can choose one of the PSU's manufacture dates to be displayed on the screen through the "UP"/"DOWN" buttons.

Once you enter this page, you can choose one of the PSU's firmware versions to be displayed on the screen through the "UP"/"DOWN" buttons.

#### **4.2.5 Condition of Programmable Relay**

In the "Prog. Relay" section, it displays the condition of each programmable relays. "x" indicates that the relay is inactive and its COM contacts the "NC". "o" indicates that the relay is activated, and its COM is contacting the "NO".

#### **4.2.6 RKP-CMU1 Information**

In the "RKP-CMU1 Info." section, there are the serial number, the manufacture date, the firmware version, country of production, and the GSM phone number of the Scout-S that can be displayed by pressing the "ENT" button.

### **4.3 Settings Menu**

Under the "Settings Menu", there are PSU ON/OFF setting, Bus voltage setting, PSU current setting, PSU alarm setting, programmable relay setting, Data Log Interval, communication port setting (USB/RS232), date and time setting, buzzer ON/OFF setting, and Scout-S address setting that can be selected through the "UP"/"DOWN" buttons.

#### **4.3.1 PSU ON/OFF Setting**

In this page, you can enter PSU ON/OFF setting by pressing the "ENT" button when this option is on the screen.




Once you entered this screen, you can choose which PSU you would like to turn on or off through the "UP"/"DOWN" buttons. It is also possible to control the whole units by changing "xxx" to "ALL". "xxx" indicates PSU's number.

If "OFF (Alarm)", or "N/A" is displayed, that means the PSU is in an abnormal situation or offline. In this case, the PSU cannot be controlled.

Once you have chosen a PSU, pressing the "ENT" button will change its setting (on or off).

Once you chose all units, the displayed screen will show as below. "yy" indicates numbers of units set to be ON, "zz" indicates numbers of units set to be OFF, "FULL OFF" indicates all the units set to be OFF, and "FULL ON" indicates all the units set to be ON. For changing the setting (on or off), press the "ENT" button.



#### 4.3.2 Bus Voltage Setting

Once you entered this page, you can trim the Bus voltage through the "UP"/"DOWN" buttons. Refer to the Table of PSU adjustable voltage range.

PSU adjustable voltage range:

Model	Bus Voltage Range	Default
12V	10.5 ~ 14V	13.6V

#### 4.3.3 PSU Current Setting

In the "Set PSU Current" section, you can enter PSU current setting by pressing the "ENT" button when this option is on the screen.

Once you entered this page, you can trim the output current through the "UP"/"DOWN" buttons. Refer to the Table of PSU adjustable current range.

PSU adjustable current range:

Model	PSU Current Range	Default
12V	30 ~ 112A	100A

Note : If the set PSU current exceeds 100A, the maximum rated current, OTP might be triggered after operating a period of time.

#### 4.3.4 Programmable Relay Setting

When the "Set Prog. Relay" option is on the screen, you can enter programmable relay settings by pressing the "ENT" button. (Default value: Alarm (activate) Any Alarm)

Once you entered this page, you can choose which relay you would like to modify through the "UP"/"DOWN" buttons. There are four relays available to be selected.

Each relay can be set for the functions below :

1. Alarm activating: Any Alarm, OVP, OLP, OTP, Short circuit, High Temp., AC Fail, Fan lock, or PMBus Error.
2. PSU ON activating: Immediately, or Delay (1~600 sec).
3. PSU OFF activating: Immediately, or Delay (1~600 sec).
4. Digital I/P activating: Control by DI1, control by DI2, control by DI3, or control by DI4.

#### 4.3.5 Data Log Interval Setting

Once you entered this page, you can set Data Log's time interval, from 1 to 60 minutes, through the "UP"/"DOWN" buttons. (Default value: 5 minutes)

#### 4.3.6 Communication Port Setting (USB/RS232)

In the "Set USB/RS232" section, there are USB, RS232, and RS232 for GSM interface that can be selected. (Default: USB)

#### 4.3.7 Date and Time Setting

Under "Set Date/Time", "yy" indicates year, "mm/dd" indicates month/day, and "HH/MM" indicates hour/minute. Press the "ENT" button to select year, month, day, hour, or minute. Then, use the "UP"/"DOWN" buttons to choose a number.

#### **4.3.8 Buzzer ON/OFF Setting**

Under "Buzzer Control", you can turn buzzer on or off by pressing the "ENT" button. (Default:OFF Buzzer)

#### **4.3.9 Scout-S Address Setting**

In the "Scout-S address" section, you can set Scout-S's address by pressing the "ENT" button. (Default: 1)

#### **4.4 Maintenance Menu**

A password is required to enter this menu. Once you entered this menu, there are "view Event Log", "clear Event Log", "clear Data Log", "change password", and "load default settings" that can be selected.

Four digits are needed for a password, entering a password can use the "UP"/"DOWN" buttons to choose a number, from 0 to 9, then press the "ENT" button to the next digit. (Default password: 0000)

##### **4.4.1 View Event Log**

The Event log stores abnormal system conditions when alarms occur. It is capable of saving up to 600 records and the contents include time, type of alarm, which PSU.

Once you entered this page, you can choose a LOG number or a date through the "UP"/"DOWN" buttons to access the information you need.

Once you chose a LOG number/date, it will display when it occurs and which types of alarm it is.

##### **4.4.2 Clear Event Log**

The "Clear Event Log" function is used to clear all the data that Event log has stored.

##### **4.4.3 Clear Data Log**

The "Clear Data Log" function is used to clear all the data that Data log has stored.

The content of Data log include AC voltage, relay condition, condition of digital input signal, output voltage, total output current, each PSU's currents, and time. The content of Data log is possible to be accessed by the built-in web page or monitoring software.

##### **4.4.4 Change Password**

The "Change Password" function is used to change a password for entering the "Maintenance Menu".

##### **4.4.5 Load Default Setting**

The "Load Default" is used to reset the parameters of the "Settings Menu" to its default value.

#### **4.5 Network Menu**

Once you entered the "Network Menu", there are MAC address, IP address, subnet mask, and gateway (support IP v4) that can be selected.

##### **4.5.2 MAC Address**

Each Scout-S unit has a different MAC address, and the address is assigned by the internal hardware.

##### **4.5.2 IP Address**

IP address can be changed by the built-in web page, but doing so requires the Scout-S and the PC you use in the same domain. (Default IP: 169.254.1.1)

##### **4.5.3 Subnet Mask**

Subnet mask can be changed by the built-in web page, but doing so requires the Scout-S and the PC you use in the same domain. (Default IP: 255.255.0.0)

##### **4.5.4 Gateway**


Gateway can be changed by the built-in web page, but doing so requires the Scout-S and the PC you use in the same domain. (Default IP: 169.254.1.1)

## 5. Scout-S Web Page Monitoring Functions

### ◎ System requirements

1. Windows XP, Windows Vista, or Windows 7 operating system
2. AMD or Intel Pentium 133MHz or better based computer
3. 10/100 BASE-T Ethernet port
4. Microsoft IE6 (and above)

### ◎ Connection diagram



◎ Before accessing the built-in web page, please make sure that the Scout-S and the PC you use are set in the same domain. If this is the first time you access the built-in web page, you will need to change the IP address of your PC. Once you are connected to the built-in web page, change of the Scout-S's address settings (like to another domain) can be done.


### ※ Default address of Scout-S

Address	Default
IP address	169.254.1.1
Subnet mask	255.255.0.0
Default gateway	169.254.1.1

### 5.1 IP Setting of PC


Please follow the following instruction to set the IP address of your PC.

- (1) Only connect your PC to the Scout-S, and verify that there are no other devices connecting to your PC like a modem.
- (2) Click the "Network and Internet Connections" option. Then click the "Local Area Connection". Select "Internet Protocol (TCP/IP)", and then click the "Properties" button. If there are "Internet Protocol Version 4 (TCP/IPv4)" and "Internet Protocol Version 6 (TCP/IPv6)" shown on the table, choose "Internet Protocol Version 4 (TCP/IPv4)".



- (3) Click the "Use the following IP address", and then type addresses in "IP address", "Subnet mask", and "Default gateway" boxes. After that click the "OK" button. The IP address you set should be in the same domain Scout-S but not the identical IP. There is an example below for your reference.

Address	Default (for ex.)
IP address	169.254.1.2
Subnet mask	255.255.0.0
Default gateway	169.254.1.1



(4) Check if it is working correctly by clicking the "Support". If the addresses presented as you typed, it is successfully done. Then you can access the built-in web page.




If the table shows as below, it means that your RJ-45 cable is not properly connected or the IP address you have set is incorrect.



## 5.2 Description of Scout-S Built-in Web Page

### 5.2.1 How to open the website

Connect your PC to the Scout-S, then open a blank page and type the IP address of the Scout-S in the address bar. If you are not sure the IP address of Scout-S, refer to the LCD user interface. The route is "Main Page" → "Menu Page" → "IP Address". (Default IP: 169.254.1.1)



Default: 169.254.1.1




### 5.2.2 CMU Status Page

The home page of the built-in web page is the "SCU Status". This page displays important information including Bus voltage, total output current, the conditions of digital input signals, the conditions of programmable relays, the information of Scout-S, PSU status, and numbers of online units.

A screenshot of the Scout-S web page. The page has a dark blue header with the text "Powering the Network" and a small image of a network device. On the left side, there is a vertical menu with red buttons for "SCU Status", "PSU Status", "Configuration", "EventLOG", "DataLOG", and "TCP/IP Config.". The main content area is divided into several sections: "Bus Voltage / Output Current Display" showing "Bus Voltage : 0V" and "Output Current : 0A"; "Relay Status" showing "Relay1:ON", "Relay2:ON", "Relay3:ON", and "Relay4:ON"; "Digital input Status" showing "Input1:HIGH", "Input2:HIGH", "Input3:HIGH", and "Input4:HIGH"; "Scout Information" showing "Location : TWN", "Serial: 140522000045", "Date: 2014/05/22/", and "Revision: R01.1"; and a "Total connection:0PSU" section with a table of 32 connections (00:N/A to 31:N/A). A legend at the bottom right indicates "Red:PSU OFF", "Green:PSU ON", and "N/A:No connect".

### 5.2.3 PSU Status Page

The "PSU Status" page displays the operating information of each PSU, including output current, internal temperature, serial number, firmware version, alarm, and status.



The screenshot shows a web interface titled "Powering the Network" with a navigation menu on the left and a table of PSU status data. The navigation menu includes: SCU Status, PSU Status, Configuration, EventLOG, DataLOG, and TCP/IP Config. The table lists 17 PSUs with columns for PSU, Current, Temperature, SerialNo., FirmwareVer, Alarm, and Status.

PSU	Current	Temperature	SerialNo.	FirmwareVer	Alarm	Status
0	0	29	N/A	N/A	Normal	ON
1	0	0	N/A	N/A	N/A	N/A
2	0	0	N/A	N/A	N/A	N/A
3	0	0	N/A	N/A	N/A	N/A
4	0	0	N/A	N/A	N/A	N/A
5	0	0	N/A	N/A	N/A	N/A
6	0	0	N/A	N/A	N/A	N/A
7	0	0	N/A	N/A	N/A	N/A
8	0	0	N/A	N/A	N/A	N/A
9	0	0	N/A	N/A	N/A	N/A
10	0	0	N/A	N/A	N/A	N/A
11	0	0	N/A	N/A	N/A	N/A
12	0	0	N/A	N/A	N/A	N/A
13	0	0	N/A	N/A	N/A	N/A
14	0	0	N/A	N/A	N/A	N/A
15	0	0	N/A	N/A	N/A	N/A
16	0	0	N/A	N/A	N/A	N/A

### 5.2.4 Configuration Page

Once you clicked the "Configuration" page, you will be asked to enter a user name and a password. Refer to the label on the top panel for both the "User name" and "Password". This user name and password cannot be changed.



Note: See label on top panel for username and password.



Once you insert the correct user name and password, you will enter the settings page. On this page, there are Bus voltage, PSU over-current, clear Event Log/Data Log, Data Log time interval setting, programmable relay setting, and PSU ON/OFF that can be set and altered.


#### 5.2.4.1 Bus Voltage / PSU Current

If the Bus voltage/PSU current you set is not within the adjustable range, it will become invalid. Make sure the parameters that you type in are not over or less than the range as below.

Adjustable range of Bus voltage/ PSU current:


Model	Bus voltage range	PSU current range
12V	10.5 ~ 14V	30 ~ 112A

Note : If the set PSU current exceeds 100A, the maximum rated current, OTP might be triggered after operating a period of time.



#### 5.2.4.2 Setting of Clear EventLog/DataLog and DataLog Time Interval

The "Set Clear EventLog/DataLog" box is used to clear the data that Event log/Data log has stored, while the "Set DataLog time interval" box can set the time interval from 1 to 60 minutes.



#### 5.2.4.3 Setting of Programmable Relay

Each relay can be set for the functions below :

1. Alarm activating: Any Alarm, OVP, OLP, OTP, Short circuit, High Temp., AC Fail, Fan lock, or PMBus Error.
2. PSU\* ON activating: Immediately, or Delay (1~600 sec).
3. PSU\* OFF activating: Immediately, or Delay (1~600 sec).
4. Digital I/P activating: Control by DI1, control by DI2, control by DI3, or control by DI4.



\*Note: PSU=Scout-R Rectifier

**Set Relay :**

Relay	Function	Sub Function	PSU	Delay sec
Relay	Alarm	-Select		(1~600)

Save Relay

**Set PSU ON/OFF :**

00	01	02	03	04	05
		N/A	N/A		N/A
16	17	18	19	20	21

Then, click the scroll-down list of the "Sub Function" to choose an activation type

**Set Relay :**

Relay	Function	Sub Function	PSU	Delay sec
Relay	PSU ON	Delay	PSU01	12 (1~600)

Save Relay

Type a delay time value to decide how much time it need to be delayed

### 5.2.4.3 PSU ON/OFF setting

If you would like to turn a PSU\* on or off, double click its status bar under its number. "Green" indicates "PSU ON", "Red" indicates "PSU OFF", and "N/A" indicates "unconnected". If you double click a status bar displayed green, it will shift to red, whereas if the status bar you double clicked is red, it will switch to green. If a status bar displays "N/A", it cannot be controlled due to non-connection to the Scout-S. Turning the whole PSU units on or off is also possible by clicking the "ALL PSU ON"/ "ALL PSU OFF" buttons. The updated status will not immediately reflect in its status bar, it may delay 1~3 seconds.

**Set PSU ON/OFF :**

00	01	02	03	04	05	06	07	08	09	10	11	12	13	14	15
		N/A	N/A	N/A	N/A	N/A	N/A	N/A	N/A	N/A	N/A	N/A	N/A	N/A	N/A
16	17	18	19	20	21	22	23	24	25	26	27	28	29	30	31
N/A	N/A	N/A	N/A	N/A	N/A	N/A	N/A	N/A	N/A	N/A	N/A	N/A	N/A	N/A	N/A

All PSU ON All PSU OFF


Status bar

\*Note: PSU= Scout Rectifier

### 5.3 Event Log Page

The Event Log stores abnormal system situations when alarms occur. It is capable of saving 600 records, but if the stored data is over its capacity, it will overwrite the previous data, from the first record. The contents that Event Log stores include time, type of alarm, and which PSU. The "EventLog" page displays 10 records in one page, and pages can be selected by the "scroll-down list".

*Powering the Network*



SCU Status	PSU Status	Configuration	EventLOG	DataLOG	TCP/IP Config.

Number	PSU/SCU	Alarm	Time
1	SCU	PMBus Error,	2014-09-23 09:43:58
2	PSU00	Fan2 Fault,	2014-09-23 09:46:26
3	SCU	Alarm Remove	2014-09-23 09:46:26
4	PSU00	AC Fault, Fan2 Fault,	2014-09-23 09:47:03
5	PSU00	Alarm Remove	2014-09-23 09:47:07
6	SCU	PMBus Error,	2014-09-23 09:47:08
7	SCU	Alarm Remove	2014-09-23 10:15:57
8	PSU00	Fan2 Fault,	2014-09-23 10:15:58
9	PSU00	Alarm Remove	2014-09-23 10:20:03
10	SCU	PMBus Error,	2014-09-23 10:20:04

-select- Page

### 5.4 Data Log Page

The Data Log will save operating data at regular intervals set by "Data log interval". The Data Log is capable of saving 1000 records, but if the stored data is over its capacity, it will overwrite the previous data, from the first record. The contents that Data Log stores include AC voltage, relay condition, condition of digital input signal, output voltage, total output current, each PSU's currents, and time. The "DataLog" page displays 10 groups of data in one page, and pages can be selected by the "scroll-down list".


N	Relay	D.Input	BusV	TotalI	Vac	PSU I (A)								Time																								
						00:(0)	08:(0)	16:(0)	24:(0)	01:(0)	09:(0)	17:(0)	25:(0)		02:(0)	10:(0)	18:(0)	26:(0)	03:(0)	11:(0)	19:(0)	27:(0)	04:(0)	12:(0)	20:(0)	28:(0)	05:(0)	13:(0)	21:(0)	29:(0)	06:(0)	14:(0)	22:(0)	30:(0)	07:(0)	15:(0)	23:(0)	31:(0)
1	R1:OFF R2:OFF R3:OFF R4:OFF	D1:High D2:High D3:High D4:High	13.5V	0A	Max: 117.5V Min: 117.5V	00:(0)	08:(0)	16:(0)	24:(0)	01:(0)	09:(0)	17:(0)	25:(0)	02:(0)	10:(0)	18:(0)	26:(0)	03:(0)	11:(0)	19:(0)	27:(0)	04:(0)	12:(0)	20:(0)	28:(0)	05:(0)	13:(0)	21:(0)	29:(0)	06:(0)	14:(0)	22:(0)	30:(0)	07:(0)	15:(0)	23:(0)	31:(0)	2014-09-18 08:43
2	R1:OFF R2:OFF R3:OFF R4:OFF	D1:High D2:High D3:High D4:High	13.5V	0A	Max: 117.5V Min: 117.5V	00:(0)	08:(0)	16:(0)	24:(0)	01:(0)	09:(0)	17:(0)	25:(0)	02:(0)	10:(0)	18:(0)	26:(0)	03:(0)	11:(0)	19:(0)	27:(0)	04:(0)	12:(0)	20:(0)	28:(0)	05:(0)	13:(0)	21:(0)	29:(0)	06:(0)	14:(0)	22:(0)	30:(0)	07:(0)	15:(0)	23:(0)	31:(0)	2014-09-18 08:48
3	R1:OFF R2:OFF R3:OFF R4:OFF	D1:High D2:High D3:High D4:High	13.5V	0A	Max: 117.5V Min: 117.5V	00:(0)	08:(0)	16:(0)	24:(0)	01:(0)	09:(0)	17:(0)	25:(0)	02:(0)	10:(0)	18:(0)	26:(0)	03:(0)	11:(0)	19:(0)	27:(0)	04:(0)	12:(0)	20:(0)	28:(0)	05:(0)	13:(0)	21:(0)	29:(0)	06:(0)	14:(0)	22:(0)	30:(0)	07:(0)	15:(0)	23:(0)	31:(0)	2014-09-18 08:52

### 5.5 TCP/IP Configuration Page

To enter the "TCP/IP Config." page, you will be asked to enter a user name and a password too. Refer to the label on the top panel for both the "User name" and "Password". This user name and password cannot be changed.



Once you insert the correct user name and password, you will enter this address settings page. On this page, there are IP address, subnet mask, gateway, primary DNS, and secondary DNS that can be set and changed. For example, if the Scout-S is not in your current domain, you can revise it to your current domain by changing those IP address parameters.



The screenshot shows a web-based configuration interface for a device. At the top, there is a header with the text "Powering the Network" and a small image of a network device. Below the header is a navigation menu with several red buttons: "SCU Status", "PSU Status", "Configuration", "EventLOG", "DataLOG", and "TCP/IP Config.". The "TCP/IP Config." button is highlighted. To the right of the menu is a configuration form with the following fields: "MAC Address:" (00:04:A3:86:33:15), "Host Name:" (SCOUT), "IP Address:" (169.254.1.1), "Gateway:" (169.254.1.1), "Subnet Mask:" (255.255.0.0), "Primary DNS:" (169.254.1.1), and "Secondary DNS:" (0.0.0.0). There is a "Save Config" button at the bottom of the form. Below the form, it says "TCP/IP Firmware version:RD1.1".

## 6. Scout-S Monitoring Software

### System requirements


1. Windows XP, Windows Vista, or Windows 7 operating system
2. AMD or Intel Pentium 133MHz or better based computer
3. USB 1.1 or higher
4. RKP-CMU1 monitoring software

### 6.1 Installation

(1) Install "Prolific USB driver" (PL2303\_Prolific\_DriverInstaller\_v1417.exe) onto your PC if this is the first time to run this software.

Note: If there is the need for an updated driver version for your device, refer to Prolific official website.


<http://www.prolific.com.tw/eng/downloads.asp?ID=31>



(2)Install Microsoft Framework4 (dotNetFx40\_Full\_x86\_x64.exe).

Note: If there is the need for an updated Framework4 version, refer to Microsoft website.

<http://www.microsoft.com/download/en/details.aspx?id=17851>




(3)Connect the Scout-S to your PC via a USB cable.(4)Execute RKP-CMU1.exe.



## 6.2 Using RS232 for Communication with Scout-S

The Scout-S can not only use USB interface for PC connection, but can also use the RS-232 interface. There is a RS-232 port (Male) on the rear of the Scout-S, you can use a DB9 Female - DB9 Female cable for connection between the Scout-S and your PC. Pin description shows as below.



## 6.3 Description of Scout-S Monitoring Software

⊙Before running the monitoring software, please make sure the following arrangement is done correctly. 1.Interface cable is connected between your PC and the Scout-S.

2.The Scout-S is powered on and ready.

3.Verify your interface settings are correct. Refer to the LCD user interface (section 4.4.6)

### 6.3.1 Comm. Setup Page

Once this software is running, there are some settings that must be done before accessing the Scout-S.

Step 1: COM Port Setting

1.Select the correct port for your interface cable.

2.Select a proper baud rate for data transmission. (Maximum: 115.2k).



Step 2: Address Setting


Select the correct address for the Scout-S. Refer to the LCD user interface, Section 4.4.9: Scout-S Address setting(Default:1).





Step 3 : Connection


Click the "Connect" button to access the Scout-S. If a connection was successfully established with the Scout-S, it will display "COMx Connected". If a connection failed, it will display "Comm. fail".



Connection was successful.




Connection failed. Make sure the interface cable is properly connected between your PC and the Scout-S, and make sure the parameters you set are correct.



### 6.3.2 CMU Status Page

The "CMU Status" page displays information which is more important, including Bus voltage, total output current, the conditions of digital input signals, the conditions of programmable relays, the information of Scout-S, PSU status, and numbers of online units.





### 6.3.3 PSU Status Page

The "PSU Status" page displays the operating information of each PSU, including output current, internal temperature, serial number, firmware version, alarm, and status.

PSU	Current	Temperature	Serial Number	Firmware Version	Status	Alarm
0	19.0	24	110607000006	R01.4	ON	Normal
1	00.0	24	110607000006	R01.4	OFF	Normal
2	--	--	--	--	N/A	--
3	--	--	--	--	N/A	--
4	--	--	--	--	N/A	--
5	--	--	--	--	N/A	--
6	--	--	--	--	N/A	--
7	--	--	--	--	N/A	--
8	--	--	--	--	N/A	--
9	--	--	--	--	N/A	--
10	--	--	--	--	N/A	--
11	--	--	--	--	N/A	--
12	--	--	--	--	N/A	--
13	--	--	--	--	N/A	--

### 6.3.4 Config. Page

On this page, there are Bus voltage, PSU current, clear Event Log/Data Log, Data Log time interval setting, programmable relay setting, and PSU ON/OFF that can be set and altered.

#### 6.3.4.1 Bus Voltage / PSU Current

If the Bus voltage/PSU current you set is not within the adjustable range, it will become invalid. Make sure the parameters that you type in are not over or less than the range as below. After settings, click the "Save" button to save your parameters.

Adjustable range of Bus voltage/ PSU current:

Type	Bus voltage range	PSU current (Output Current) range
12V	10.5 ~ 14V	30 ~ 112A


Note : If the set PSU current exceeds 100A, the maximum rated current, OTP might be triggered after operating a period of time.

Adjustable range

PSU	Status	PSU	Status
0	ON	16	N/A
1	OFF	17	N/A
2	N/A	18	N/A
3	N/A	19	N/A
4	N/A	20	N/A
5	N/A	21	N/A
6	N/A	22	N/A
7	N/A	23	N/A
8	N/A	24	N/A
9	N/A	25	N/A
10	N/A	26	N/A
11	N/A	27	N/A
12	N/A	28	N/A
13	N/A	29	N/A
14	N/A	30	N/A
15	N/A	31	N/A

### 6.3.4.2 Setting of Clear Event Log/Data Log and Data Log Time Interval

The "Event Log" and "Data Log" buttons are used to clear the data that Event log/Data log has stored. The "Data Log interval" is used to set the time interval from 1 to 60 minutes.



### 6.3.4.3 Setting of Programmable Relay

"Relay Setting" section is used to set activating conditions of the programmable relays. After setting, click the "save" button to save your setting values.

Each relay can be set for the functions below :

1. Alarm activating: Any Alarm, OVP, OLP, OTP, Short circuit, High Temp., AC Fail, Fan lock, or PMBus Error.
2. PSU ON activating: Immediately, or Delay (1~600 sec).
3. PSU OFF activating: Immediately, or Delay (1~600 sec).
4. Digital I/P activating: Control by DI1, control by DI2, control by DI3, or control by DI4.



### 6.3.4.4 PSU ON/OFF setting

Turning a unit or all the units on/off can be done by selecting the "scroll-down list". "ON(green)" indicates "PSU ON", "OFF(red)" indicates "PSU OFF", and "N/A(orange)" indicates "unconnected". Once you have chosen a PSU, you can click the "ON" or "OFF" buttons to turn it on/off. If the status column displays "N/A(orange)", it cannot be controlled due to non-connection to the Scout-S.

The screenshot shows the 'Config' tab of the RKP-CMU1 Software. On the left, there are three sections: 'Output Setting' (Bus Voltage: 13.6 V, Output Current: 47.0 A), 'Event Log / Data Log Setting' (Data Log Interval: 1 Min.), and 'Relay Setting' (Relay: Relay1, Function: Digital Input, Sub-function: DI1). On the right, the 'PSU ON/OFF Control' section contains a table with 16 rows (PSU 0 to 15) and 4 columns (PSU, Status, PSU, Status). The status for PSU 0 is 'ON', PSU 1 is 'OFF', and others are 'N/A'. Below the table is a control for PSU 1 with 'ON' and 'OFF' buttons. A red dashed box highlights the table and control area, with a red arrow pointing to it labeled 'Status table'. Another red dashed box highlights the 'Relay Setting' section, with a red arrow pointing to it labeled 'Scroll-down list and setting buttons'.

PSU	Status	PSU	Status
0	ON	16	N/A
1	OFF	17	N/A
2	N/A	18	N/A
3	N/A	19	N/A
4	N/A	20	N/A
5	N/A	21	N/A
6	N/A	22	N/A
7	N/A	23	N/A
8	N/A	24	N/A
9	N/A	25	N/A
10	N/A	26	N/A
11	N/A	27	N/A
12	N/A	28	N/A
13	N/A	29	N/A
14	N/A	30	N/A
15	N/A	31	N/A


### 6.3.5 Event Log Page

The Event Log stores abnormal system situations when alarms occur. It is capable of saving up to 600 records, but if the stored data is over its capacity, it will overwrite the previous data, from the first record. The contents that Event Log stores include time, type of alarm, and which PSU it is. If you would like to check the data that Event Log has stored, click the "Read Log".

The screenshot shows the 'Event Log' tab of the RKP-CMU1 Software. It displays a table with columns 'Log No.', 'PSU/CMU', 'Event', and 'Date/Time'. The table is currently blank, with a red box highlighting the empty area and the text 'Blank page before reading data'. At the bottom left, there is a 'Read Log' button highlighted with a red dashed box and a red arrow pointing to it labeled 'Read button'. A 'Save Log' button is also visible next to it.


Log No.	PSU/CMU	Event	Date/Time
1			
2			
3			
4			
5			
6			
7			
8			
9			
10			
11			
12			
13			
14			
15			
16			
17			
18			

After reading from the Scout-S, the data will be arranged in ascending order of Log No.. Sorting the data into other orders is also possible by clicking the column headers. Clicking the "Save Log" button can save the data onto your PC.



### 6.3.6 Data Log Page

The Data Log will save operating data at regular intervals set by "Data log interval". The Data Log is capable of saving 1000 records, but if the stored data is over its capacity, it will overwrite the previous data, from the first record. The contents that Data Log stores include AC voltage, relay condition, condition of digital input signal, output voltage, total output current, each PSU's currents, and time. If you would like to check the data that Data Log has stored, click the "Read Log".



After reading from the Scout-S, the data will be arranged in ascending order of Log No.. Sorting the data into other orders is also possible by clicking the column headers. Clicking the "Save Log" button can save the data onto your PC.




LOG No.	Relay1	Relay2	Relay3	Relay4	Input1	Input2	Input3	Bus Volt	Output Current	Max Vdc	Min Vdc
1	ON	ON	ON	ON	HIGH	HIGH	HIGH	3.0	0.0	0.0	0.0
2	ON	ON	ON	ON	HIGH	HIGH	HIGH	3.0	0.0	0.0	0.0
3	ON	ON	ON	ON	HIGH	HIGH	HIGH	3.0	0.0	0.0	0.0
4	ON	ON	ON	ON	HIGH	HIGH	HIGH	3.0	0.0	0.0	0.0
5	ON	ON	ON	ON	HIGH	HIGH	HIGH	3.0	0.0	0.0	0.0
6	ON	ON	ON	ON	HIGH	HIGH	HIGH	3.0	0.0	0.0	0.0
7	ON	ON	ON	ON	HIGH	HIGH	HIGH	3.0	0.0	0.0	0.0
8	ON	ON	ON	ON	HIGH	HIGH	HIGH	3.0	0.0	0.0	0.0
9	ON	ON	ON	ON	HIGH	HIGH	HIGH	3.0	0.0	0.0	0.0
10	ON	ON	ON	ON	HIGH	HIGH	HIGH	3.0	0.0	0.0	0.0
11	ON	ON	ON	ON	HIGH	HIGH	HIGH	3.0	0.0	0.0	0.0
12	ON	ON	ON	ON	HIGH	HIGH	HIGH	3.0	0.0	0.0	0.0
13	ON	ON	ON	ON	HIGH	HIGH	HIGH	3.0	0.0	0.0	0.0
14	ON	ON	ON	ON	HIGH	HIGH	HIGH	3.0	0.0	0.0	0.0
15	ON	ON	ON	ON	HIGH	HIGH	HIGH	3.0	0.0	0.0	0.0
16	ON	ON	ON	ON	HIGH	HIGH	HIGH	3.0	0.0	0.0	0.0
17	ON	ON	ON	ON	HIGH	HIGH	HIGH	3.0	0.0	0.0	0.0

Sorting data can be done by clicking a column header

Save button Chart button

This page also offers a function that presents the Data log data in column charts by clicking the "Chart" button. Once column charts are created, tendency of the data can be seen on your PC. Except for "Vbus" and "Iout" that are fixed on the page, others like I0~I7 (PSU0~7 Iout), I8~I15 (PSU8~15 Iout), I16~I31 (PSU16~31 Iout), and Vac max/min (the maximum/minimum AC input) can be selected by the "scroll-down list".




### 6.3.7 TCP/IP & GSM Page

This page can be split into 2 parts. One is for displaying the information of TCP/IP, including MAC address, IP address, subnet mask, and gateway. The other is for setting your GSM phone number. After typing your numbers in the column, click the "Save" button to save your phone number. "Unspecified" indicates that there's no phone number been stored yet.

TCP/IP information

GSM phone number setting

Type a GSM phone number ° (ex: 1234567890)



## 7. GSM Short Message Functions

### System Requirements:

1. GSM modem with antenna
2. Interface cable for GSM modem
3. SIM card


### Notes:

1. The Scout-S is in compliance with AT-commands for sending GSM messages. For using this function, a GSM modem equipped with those AT-commands that "Section 7.3" mentioned is needed. Refer to the product below.  
Sierra Wireless, AirLink™ Programmable Modems  
[http://www.sierrawireless.com/productsandservices/AirLink/Programmable\\_Modems.aspx](http://www.sierrawireless.com/productsandservices/AirLink/Programmable_Modems.aspx)
2. Follow the instruction of the user manual of your GSM modem and the instruction below to properly set the connection between your GSM modem and the Scout-S. Also make sure the baud rate of the GSM modem is set at 115200bps.

### 7.1 Installation and Settings

- (1) Insert a SIM card into your GSM modem. Make sure that there is no PIN (Personal Identification Number) recorded in the SIM card.
- (2) After installing a GSM antenna to your GSM modem and connecting an interface cable between the Scout-S and your GSM modem, turn the GSM modem on.

The figure below shows the connection diagram for a Scout-S and a GSM modem.





- (3) Set a GSM phone number in the Scout-S. Refer to "Section 6.3.7".
- (4) Select "3: RS232 for GSM" in the "Communication Port Setting" through the LCD user interface. Refer to "Section 4.4.6".

**7.2 Test of Sending a Short Message**

- (1) Turn devices on in the following order:, Scout-S, and then GSM modem.
- (2) Unplug the power of the Scout-R.
- (3) In this case, there is a "PMBus Error" alarm that will occur. Then, you should receive a text message sent by the Scout-S after a few seconds.

**7.3 AT-Command List for Scout-S**

Command	Description
AT	Attention Command
AT+CNMI	New Message Indication
AT+CSMP	Set Text Mode Parameters
AT+CMGF	Preferred Message Format
AT+CMGS	Send Message

**8 EMI Suppression Arrangement**

- ⊙EMI radiation test is greatly affected by wiring. Attaching an EMI suppressor (ferrite core) to the AC cable as close as possible to the AC inlet to reduce the noise is recommended. There are suggested components for reducing EMI radiation interference including TDK HF70RU26\*29\*13S, NEC ESD-SR-250H, and EROCORE FH29.7\*13\*25.9.
- ⊙When using a RJ-45 cable as your interface cable, it might be needed to attach an EMI suppressor (ferrite core) to the cable as close as possible to the Ethernet connector (JK1) to reduce EMI radiation interference. There are TDK ZCAT2032-0930, NEC ESD-SR-160, and EROCORE FH 28x9x16 available for that purpose.

**9 Troubleshooting**

Issue	Possible Cause	Solution
No Power	1) RKP-1U not installed on SK1000	1) Verify
	2) No AC Input	2) Verify proper AC input
	3) Defective Scout-R Rectifier	3) Contact Technical Service
Controller does not turn on	1) DC is not connected	1) Verify that DC barrel connector is fully plugged in at rear of unit
	2) Blown "DC In" fuse	2) Contact Technical Service
	3) All Scout-R Rectifiers were turned off and no battery connected	3) External 12V, 1A supply must be connected to DC In to re-enable DC output on at least one rectifier
Cannot connect to web interface	1) Computer and system not in same domain	1a) Use crossover cable to connect directly to Scout-S and verify correct IP configuration 1b) use USB and RKP-Cmu-1 software to connect to Scout and verify correct IP configuration
	2) Network conflict	2) Contact your IT department. Verify Firewall and IP configuration
Cannot connect through USB	1) Software nont installed	1) install Prolific driver
	2) Incorrect port selection in Comm settings	2) On PC, verify port number in windows device manager


**10 Warranty & Contact**

- ⊙Newmar warrants that the ScoutPower System to be free from defects in material an workmanship for two years from date of purchase. If youhave a problem with your unit or if you have any questions about the instillation or proper operation of the unit, please contact NEWMAR's Technical Service Department:  
 Phone (714)751-0488 From the hours of 7:30 a.m. to 5:00 p.m. weekdays P.S.T.  
 Fax (714) 957-1621  
 E-mail: techservice@newmarpower.com


# APPENDIX:

## App. A Main Specification

<b>MODEL</b>		<b>Scout-S</b>
<b>OUTPUT</b>	<b>DIGITAL METER</b>	Display the DC output voltage, current, and internal temperature of each Scout-R unit
	<b>CONTROL OUTPUT</b>	PM Bus signal for each Scout-R unit
	<b>LED INDICATOR</b>	Green: Power on Red:Alarm
	<b>RELAY CONTACT</b>	4 user programmable relay, relay contact rating(max.): 30V/1A resistive
<b>DC Input</b>	<b>VOLTAGE RANGE</b>	12 ~ 15VDC
	<b>CURRENT</b>	1A/12VDC 0.8A/15VDC
<b>FUNCTION</b>	<b>DISPLAY</b>	LCD 16x2 Alphanumeric Matrix Display / PC Web Page Display
	<b>MONITOR</b>	Output Voltage / Load Current / Temperature / Input Voltage
	<b>CONTROL</b>	Output Voltage, Current Limit, ON/OFF
	<b>COMM. INTERFACE</b>	USB, RS-232, Ethernet
<b>ENVIRONMENT</b>	<b>WORKING TEMP.</b> Note.1	-25 ~ +70°C
	<b>WORKING HUMIDITY</b>	20 ~ 90% RH non-condensing
	<b>STORAGE TEMP., HUMIDITY</b>	-40 ~ +85°C, 10 ~ 95% RH
	<b>VIBRATION</b>	10 ~ 500Hz, 2G 10min./1cycle, 60min. each along X, Y, Z axes
<b>SAFETY &amp; EMC</b>	<b>SAFETY STANDARDS</b>	UL60950-1, TUV EN60950-1 approved
	<b>WITHSTAND VOLTAGE</b> Note.2	I/P-O/P:3KVAC I/P-FG:1.5KVAC O/P-FG:0.7KVDC
	<b>ISOLATION RESISTANCE</b> Note.2	I/P-O/P, I/P-FG,O/P-FG:100M Ohms / 500VDC / 25°C / 70% RH
	<b>EMC EMISSION</b>	Compliance to EN55022 (CISPR22) Conduction Class B, Radiation Class A : EN61000-3-2,-3
	<b>EMC IMMUNITY</b>	Compliance to EN61000-4-2,3,4,5,6,8,11, EN61000-6-1(EN5008-2), light industry level, criteria A
<b>OTHERS</b>	<b>MTBF</b>	110.5K hrs min. MIL-HDBK-217F (25°C)
	<b>DIMENSION</b>	486.6*350.8*44mm (L*W*H)
	<b>PACKING</b>	4.4Kg: 3pcs/14.2Kg/2.67CUFT
<b>NOTE</b>		1. LCD may freeze under -10 °C 2. SK100 and all of signal connectors (except CN502, CN503, and USB port) are considered as O/P.



**App. B: Rear View**




**App. C: Recommended Input/Output Wire Sizes**

Input/ Output	Module	Current	Minimum Cross-section of Copper Wire	Maximum Current
115VAC	1 unit	16Arms	14AWG UL 1015	12A
230VAC	1 unit	10Arms	18AWG UL 1015	6A
+12VDC	1 unit	100A dc	2 AWG/22mm <sup>2</sup>	115A
	2 unit	200A dc	0 AWG/60mm <sup>2</sup>	217A

**App. D: De-rating**

©When Scout-R units are operating in high ambient temperature or at a low AC input voltage, these units will de-rate their output current automatically to protect themselves.



App. D Output de-rating curve for Scout-R

**App. E: LED Status**

LED	Status	Description
	Green	Power on indicator of Scout-S. It will be green while normal operation.
	Flashing red	Scout-S or Scout-R is under an abnormal situation.
	No indication	Normal condition.

**App. F: Pin Assignments**

©CN500 Pin No. Assignment

Connector Pin No. Assignment(CN500) : D-Type Right Angle 25 positions

Pin No.	Assignment	Pin No.	Assignment	Pin No.	Assignment	Pin No.	Assignment
1	ON/OFF-A	6	FAN FAIL-A	11	T-ALARM-B	16-21	N.C.
2	AC-OK-A	7	ON/OFF-B	12	FAN FAIL-B	22	+S
3	DC-OK-A	8	AC-OK-B	13	+5V-AUX	23	-S
4	PV-A	9	DC-OK-B	14	+12V-AUX	24	+V
5	T-ALARM-A	10	PV-B	15	GND-AUX	25	-V

©JK1 Pin No. Assignment

Connector Pin No. Assignment(JK1) : RJ45 8 positions

Pin No.	Assignment	Pin No.	Assignment	Pin No.	Assignment
1	DA	4	CONTROL	7	SCL
2	DB	5	NC	8	GND-AUX
3	-V	6	SDA		

©CN502 Pin No. Assignment

Connector Pin No. Assignment(CN502) : D-type Male 9 positions

Pin No.	Assignment	Pin No.	Assignment
1,4,6,7,8,9	NC	3	TXD
2	RXD	5	GND-FG

©CN503 Pin No. Assignment

Connector Pin No. Assignment(CN503) : HRS DF11-8DP-2DS or equivalent

Pin No.	Assignment	Pin No.	Assignment
1	D-IN1	5	D-IN3
2,4,6,8	GND-FG	7	D-IN4
3	D-IN2		

©JK500 Pin No. Assignment

Connector Pin No. Assignment(JK500) : RJ45 8 position

Pin No.	Assignment	Pin No.	Assignment
1	TX+	4,5,7,8	NC
2	TX-	6	RX-
3	RX+		

©TB4 Pin No. Assignment : Connector Pin No. Assignment(TB4)

DECA MX422-25412 or equivalent

Pin No.	Assignment	Pin No.	Assignment	Pin No.	Assignment	Pin No.	Assignment
1	Relay1-NO	4	Relay2-NO	7	Relay3-NO	10	Relay4-NO
2	Relay1-NC	5	Relay2-NC	8	Relay3-NC	11	Relay4-NC
3	Relay1-COM	6	Relay2-COM	9	Relay3-COM	12	Relay4-COM

©SK100 Pin No. Assignment : Connector Pin No. Assignment(SK100)

Schurter 4840.2201 or equivalent

Pin No.	Assignment	Pin No.	Assignment
1	+VIN	2	-VIN

©Description of CN502 connection pins

Pin No.	Function	Description
1,4,6,7,8,9	NC	Not used.
2	RXD	Data receiving pin of RS-232 interface.
3	TXD	Data transmitting pin of RS-232 interface.
5	GND-FG	RS-232 common GND. This signal connects to FG and isolated from -V and GND-AUX.

©Description of CN503 connection pins

Pin No.	Function	Description
1,3,5,6	D-IN1 D-IN2 D-IN3 D-IN4	The isolated digital input signal and referenced to GND-FG (pin2, 4, 6, 8). Open from GND-FG or +5V : Logic "1" input to Scout-S short to GND-FG or 0V : Logic "0" input to Scout-S
2,4,6,8	GND-FG	Common GND for D-IN. This signal connects to FG and isolated from -V and GND-AUX.

©Description of JK500 connection pins

Pin No.	Function	Description
1,2	TX+/TX-	Data transmitting pin of the Ethernet interface.
3,6	RX+/RX-	Data receiving pin of the Ethernet interface.
4,5,7,8	NC	Not used.

©Description of TB4 connection pins

Pin No.	Function	Description
1,4,7,10	Relay-NO	Normal-open contact of programmable relay.
2,5,8,11	Relay-NC	Normal-close contact of programmable relay.
3,6,9,12	Relay-COM	Common for NO/NC contact.

Note: Relay contact rating (max.): 30Vdc/1A resistive.

©Description of SK100 connection pins

Pin No.	Function	Description
1	+VIN	Positive input voltage for Scout-S controller.
2	-VIN	Negative input voltage for Scout-S controller.

©Description of JK1 connection pins

Pin No.	Function	Description
1,2	DA,DB	Differential digital signal for parallel control. (Note.1)
3	-V	Negative output voltage. For parallel control, can't be connected directly to the load.
4	CONTROL	Remote ON/OFF control pin used in the PMBus interface. (Note.2)
5	NC	Not used.
6	SDA	Serial Data used in the PMBus interface. (Note.2)
7	SCL	Serial Clock used in the PMBus interface. (Note.2)
8	GND-AUX	Auxiliary voltage output GND. The signal return is isolated from the output terminals (+V & -V).


Note.1: Non-isolated signal, referenced to the output terminals (-V).

Note.2: Isolated signal, referenced to GND-AUX.

©Description of CN500 connection pins

Pin No.	Function	Description
1,7	ON/OFF	Each unit can separately turn the output on and off by electrical signal or dry contact between ON/OFF A,B(pin 1,7) and +5V-AUX (pin 13). Short: ON, Open: OFF. (Note.2)
2,8	AC-OK	Low : When the input voltage is $\geq 87V_{rms}$ . High : when the input voltage is $\leq 75V_{rms}$ . (Note.2)
3,9	DC-OK	High : When the Vout is $\leq 80\pm 5\%$ . Low : When the Vout is $\geq 80\pm 5\%$ (Note.2)
4,10	PV	Connection for output voltage trimming. The voltage can be trimmed within its defined range. (Note.1)
5,11	T-ALARM	High : When the internal temperature (TSW1 or TSW2 open) exceeds the limit of temperature alarm. Low : When the internal temperature (TSW1 or TSW2 short) is under the limit temperature. (Note.2)
6,12	FAN FAIL	High : When the internal fan is failure. Low : When the internal fan is normal operating. (Note.2)
13	+5V-AUX	Auxiliary voltage output, 4.3-5.5V, referenced to GND-AUX (pin 15). The maximum load current is 0.3A. This output has the built-in "Oring diodes" and is not controlled by the remote ON/OFF control.
14	+12V-AUX	Auxiliary voltage output, 10.8-13.2V, referenced to GND-AUX (pin 15). The maximum load current is 0.8A. This output has the built-in "Oring diodes" and is not controlled by the remote ON/OFF control.
15	GND-AUX	Auxiliary voltage output GND. The signal return is isolated from the output terminals (+V & -V).
16-21	NC	Not used.
22	+S	Positive sensing. The +S signal should be connected to the positive terminal of the load. The +S and -S leads should be twisted in pair to minimize noise pick-up effect. The maximum line drop compensation is 0.5V.
23	-S	Negative sensing. The -S signal should be connected to the negative terminal of the load. The -S and +S leads should be twisted in pair to minimize noise pick-up effect. The maximum line drop compensation is 0.5V.
24	+V	Positive output voltage. For local sense use only, cannot be connected directly to the load.
25	-V	Negative output voltage. For local sense use only, cannot be connected directly to the load.

**App. G: LCD Display Menu Structure**



**App. H**

**Programmable Relays and Digital Input Signal**

Functions	Selections
Alarm	1.Any alarm 2.OVP 3.OLP 4.Short circuit 5.OTP 6.High temp. 7.AC fail 8.Fan lock 9.PMBus Error
PSU ON	1.Immediately 2.Delay 1 ~ 600 sec
PSU OFF	1.Immediately 2.Delay 1 ~ 600 sec
Digital Input	Control by Digital

**App. I**

**PMBus Device Addressing**

Module No.	DIP switch position				
	1	2	3	4	5
0	ON	ON	ON	ON	ON
1	OFF	ON	ON	ON	ON
2	ON	OFF	ON	ON	ON
3	OFF	OFF	ON	ON	ON
4	ON	ON	OFF	ON	ON
5	OFF	ON	OFF	ON	ON
6	ON	OFF	OFF	ON	ON
7	OFF	OFF	OFF	ON	ON
8	ON	ON	ON	OFF	ON
9	OFF	ON	ON	OFF	ON
10	ON	OFF	ON	OFF	ON
11	OFF	OFF	ON	OFF	ON
12	ON	ON	OFF	OFF	ON
13	OFF	ON	OFF	OFF	ON
14	ON	OFF	OFF	OFF	ON
15	OFF	OFF	OFF	OFF	ON

Module No.	DIP switch position				
	1	2	3	4	5
16	ON	ON	ON	ON	OFF
17	OFF	ON	ON	ON	OFF
18	ON	OFF	ON	ON	OFF
19	OFF	OFF	ON	ON	OFF
20	ON	ON	OFF	ON	OFF
21	OFF	ON	OFF	ON	OFF
22	ON	OFF	OFF	ON	OFF
23	OFF	OFF	OFF	ON	OFF
24	ON	ON	ON	OFF	OFF
25	OFF	ON	ON	OFF	OFF
26	ON	OFF	ON	OFF	OFF
27	OFF	OFF	ON	OFF	OFF
28	ON	ON	OFF	OFF	OFF
29	OFF	ON	OFF	OFF	OFF
30	ON	OFF	OFF	OFF	OFF
31	OFF	OFF	OFF	OFF	OFF

**App. J**

**PMBus Command List**

Command Code	Command Name	Transaction Type	# of data Bytes	Description
01h	OPERATION	R/W Byte	1	Remote ON/OFF control
02h	ON_OFF_CONFIG	Read Byte	1	ON/OFF function configuration
19h	CAPABILITY	Read Byte	1	Capabilities of a PMBus device
20h	VOUT_MODE	R Byte	1	Define data format for output voltage (format: Linear, N= -9)
21h	VOUT_COMMAND	R Word	2	Output voltage setting value (format: Linear, N= -9)
22h	VOUT_TRIM	R/W Word	2	Output voltage trimming value (format: Linear, N= -9)
46h	IOUT_OC_FAULT_LIMIT	R/W Word	2	Output overcurrent setting value
47h	IOUT_OC_FAULT_RESPONSE	R Byte	1	Define protection and response when an output overcurrent fault occurred
79h	STATUS_WORD	R Word	2	Summary status reporting
7Ah	STATUS_VOUT	R Byte	1	Output voltage status reporting



Command Code	Command Name	Transaction Type	# of data Bytes	Description
7Bh	STATUS_IOUT	R Byte	1	Output current status reporting
7Ch	STATUS_INPUT	R Byte	1	AC input voltage status reporting
7Dh	STATUS_TEMPERATURE	R Byte	1	Temperature status reporting
80h	STATUS_MFR_SPECIFIC	R Byte	1	Manufacture specific status reporting
81h	STATUS_FANS_1_2	R Byte	1	Fan1 and 2 status reporting
88h	READ_VIN	R Word	2	AC input voltage reading value (format: Linear, N=-1)
8Bh	READ_VOUT	R Word	2	Output voltage reading value (format: Linear, N=-9)
8Ch	READ_IOUT	R Word	2	Output current reading value (format: Linear, N=-3)
8Dh	READ_TEMPERATURE_1	R Word	2	Temperature 1 reading value (format: Linear, N=-3)
90h	READ_FAN_SPEED_1	R Word	2	Fan speed 1 reading value (format: Linear, N=4)
91h	READ_FAN_SPEED_2	R Word	2	Fan speed 2 reading value (format: Linear, N=4)
98h	PMBUS_REVISION	R Byte	1	The compliant revision of the PMBus (default: 11h for Rev. 1.1)
99h	MFR_ID	Block Read	12	Manufacturer's name
9Ah	MFR_MODEL	Block Read	12	Manufacturer's model name
9Bh	MFR_REVISION	Block Read	6	Firmware revision
9Ch	MFR_LOCATION	Block R/W	3	Manufacturer's factory location
9Dh	MFR_DATE	Block R/W	6	Manufacture date. (format: YYMMDD)
9Eh	MFR_SERIAL	Block R/W	12	Product serial number

**App. K: PMBus Data Range and Toleranc**

Display Parameters

PMBus command	Range	Tolerance
READ_VIN	0 ~ 264V	10V
READ_VOUT	0 ~ 14V	3%
READ_IOUT	0 ~125A	5A
READ_TEMPERATURE_1	0 ~ 100 °C	5 °C
READ_FAN_SPEED_1	0 ~ 20000 RPM	2000 RPM
READ_FAN_SPEED_2	0 ~ 20000 RPM	2000 RPM

Control parameters

PMBus command	Adjustable range	Tolerance	Default
OPERATION	00h(OFF) / 80h(ON)	N/A	80h(ON)
VOUT_COMMAND	12V	N/A	12V
VOUT_TRIM	-1.5~2V	5%	0V
IOUT_OC-FAULT_LIMIT	30~112A	5A	112A