


ES-4-SS AC/DC PANEL

SCALE: NONE



- 1 USE 10 AWG FOR 30 AMP SERVICE.
USE 8 AWG FOR 60 AMP SERVICE.
- 2 USE 14 AWG BULK.
USE 12 AWG FOR UP TO 25 AMPS.
USE 10 AWG UP TO 30 AMPS.
USE 8 AWG UP TO 30 AMPS.

REMARKS:
 1. CHECK WIRE TIGHTNESS AFTER
 2. INITIAL POWER UP.
 3. CONTACTS OF 30 OHM RES.
 4. WIRE TO 30 AMP FUSE.
 5. WIRE TO 30 AMP FUSE.
 6. WIRE TO 30 AMP FUSE.
 7. WIRE TO 30 AMP FUSE.
 8. WIRE TO 30 AMP FUSE.
 9. WIRE TO 30 AMP FUSE.
 10. WIRE TO 30 AMP FUSE.

WIRING DIAGRAM ES-4-SS AC/DC PANEL

31573-0

ORIGINAL